
# Wireless Lavalier Microphone



**User Manual**


MADE IN CHINA

## Product Introduction

Thank you very much for choosing our product.


This product is a wireless lavalier microphone that delivers professional-grade audio output for recording and live streaming. It is plug-and-play and requires no App. Its versatile applications include: online live streaming, video VLOG shooting, program interviews, interview recording, video teaching, and more.

The product consists of three parts: a transmitter, a receiver, and a charging case. As shown in the figure below:



Charging case Transmitter Receiver

## Product Functions




**Indicator Light 1**
Blue light blinking - Pairing
Blue light steady - Paired
Green light blinking - Charging
Green light off - Fully charged
Red light blinking - Low battery warning
Red light steady - Mute

**Indicator Light 2**
Green light steady - Noise Reduction

**Indicator Light 3**
Orange light steady - Echo

**Power Button**
Press and hold for 3s to power on
Press and hold for 3s to power off
Single click - Noise Reduction
Double click - Echo
Triple click - Mute

## Product Functions




**Indicator Light**
Blue light blinking - Pairing
Blue light steady - Paired

**Charging Port**


**Battery Indicator Light**
• ◦ ◦ ◦ —25%
• • ◦ ◦ —50%
• • • ◦ —75%
• • • • —100%

## Usage Method




## Usage Method


3.The receiver and transmitter can be used when their connection light stays on.




Note: For OPPO, VIVO, IQOO, REALME, and brands that cannot connect, please search for "OTG" in your phone's settings and turn on OTG power supply for proper operation.

## Usage Method

Connect the receiver to the data interface of the DJI action camera to use it.




## Product Operation

**Transmitter**

| Function/Status | Button/Action | Light Effect |
|---|---|---|
| Power On | Removal from charging case powers on (or press and hold Power button for 3s to power on) | Blue light blinking |
| Power Off | Placement into charging case powers off (or press and hold Power button for 3s to power off) | Light off |
| Not Connected | | Blue light blinking |
| Connected | | Blue light steady |
| Noise Reduction | Single click Power button (Click again to cancel) | Green light steady |
| Echo | Double click Power button (Double click again to cancel) | Orange light steady |
| Mute | Triple click Power button (Triple click again to cancel) | Red light steady |
| Charging | Place into charging case | Green light blinking |
| Fully Charged | | Green light off |
| Low Battery | | Red light blinking |

## Product Operation

**Receiver**

| Function/Status | Button/Action | Light Effect |
|---|---|---|
| Power On | Insert into device port for power | Blue light blinking |
| Power Off | Remove from device port to power off | Light off |
| Not Connected | | Blue light blinking |
| Connected | | Blue light steady |


**Charging Case**

| Function/Status | Action | Light Effect |
|---|---|---|
| Charging | Plug in charging cable | Blue light blinking |
| Fully Charged | | Blue light steady |
| Low Battery | | Blue light rapid blinking |

## Product Parameter

| | |
|---|---|
| Wireless Transmission | 2.4GHz |
| Transmission Delay | <20ms |
| Frequency Response | 20Hz - 20kHz |
| Sensitivity | -34dB |
| Signal-to-Noise Ratio | -65dB |
| Transmission Range | 30m-60m |
| Single Mic Runtime | 4.5H |
| Dual Mic Runtime | Up to 15+ hours with charging case |
| Input Voltage | DC4.8~5.2V |
| Transmitter Battery | 60mAh |
| Charging Case Battery | 400mAh |
| Dimensions（mm） | Transmitter: 31×16×11<br>Receiver: 30×16×7.5<br>Charging Case: 67×51×23 |
| Weight | Transmitter: 8g Receiver: 3g<br>Charging Case: 43g |

# Беспроводной микрофон



**Руководство пользователя**

MADE IN CHINA

## Описание продукта

Благодарим вас за выбор нашего продукта.


Данный беспроводной лавальный микрофон обеспечивает профессиональное качество записи и трансляции, работает без приложения (Plug-and-Play). Широкий спектр применения: Прямые онлайн-трансляции, Съёмка видеоблогов (VLOG), Телеинтервью и репортажи, Запись интервью, Видеообучение.

Комплект включает три компонента: Передатчик, Приёмник, Зарядный кейс.



Зарядный кейс Передатчик Приёмник

## Функции продукта



**Индикатор 1**
Синий мигает - Сопряжение
Синий горит постоянно - Сопряжено
Зеленый мигает - Зарядка
Зеленый гаснет - Заряд завершен
Красный мигает - Низкий заряд батареи
Красный горит постоянно - Режим тишины

**Индикатор 2**
Зеленый горит постоянно - Шумоподавление

**Индикатор 3**
Оранжевый горит постоянно - Реверберация

**Кнопка питания**
Длительное нажатие(3 сек)- Включение
Длительное нажатие(3 сек)- Выключение
Однократное нажатие - Режим шумоподавления
Двойное нажатие - Режим реверберации
Тройное нажатие - Режим тишины (Без звука)

## Функции продукта



**Индикатор подключения**
Синий мигает - Сопряжение
Синий горит постоянно - Сопряжено

**Интерфейс зарядки**

**Индикатор заряда**
• ◦ ◦ ◦ —25%
• • ◦ ◦ —50%
• • • ◦ —75%
• • • • —100%

## Инструкция по использованию




## Инструкция по использованию

3. Приемник и передатчик готовы к использованию, когда индикатор связи горит постоянно.




**Внимание:** для телефонов OPPO/VIVO/IQOO/REALME и других марок с проблемами подключения, перед использованием откройте в настройках телефона функцию «OTG» и включите «Питание через OTG».

## Инструкция по использованию

Достаточно подключить приемник к интерфейсу данных спортивной камеры DJI, чтобы начать использовать.




## Управление продуктом

**Передатчик**

| Функции/Состояния | Кнопки/Действия | Индикация |
|---|---|---|
| Включение | Извлечение из кейса Включение | Синий мигает |
| Выключение | Помещение в кейс Выключение | Индикатор выключен |
| Не подключен | | Синий мигает |
| Подключено | | Синий горит постоянно |
| Шумоподавление | Однократное нажатие | Зеленый горит постоянно |
| Реверберация | Двойное нажатие | Оранжевый горит постоянно |
| Без звука | Тройное нажатие | Красный горит постоянно |
| Зарядка | Помещение в кейс | Зеленый мигает |
| Заряд завершен | | Зеленый гаснет |
| Низкий заряд | | Красный мигает |

## Управление продуктом

**Приёмник**

| Функции/Состояния | Кнопки/Действия | Индикация |
|---|---|---|
| Включение | Подключение к устройству питание включено | Синий мигает |
| Выключение | Отсоединение питание отключено | Индикатор выключен |
| Не подключен | | Синий мигает |
| Подключено | | Синий горит постоянно |

**Зарядный кейс**

| Функции/Состояния | Действия | Индикация |
|---|---|---|
| Зарядка | Подключение кабеля | Синий мигает |
| Заряд завершен | | Синий горит постоянно |
| Низкий заряд | | Синий быстро мигает |

## Параметры продукта

| | |
|---|---|
| Беспроводная передача | 2.4 ГГц |
| Задержка передачи | <20 мс |
| Частотный диапазон | 20 Гц–20 кГц |
| Чувствительность | –34 дБ |
| Соотношение сигнал/шум | –65 дБ |
| Дальность связи | 30–60 м |
| Время работы (1 микрофон) | 4,5 ч |
| Время работы (2 микрофо на одновременно) | Максимальное время работы с зарядным кейсом: свыше 15 часов |
| Входное напряжение | 4,8–5,2 В пост. тока |
| Аккумулятор микрофона | 60 мАч |
| Аккумулятор кейса | 400 мАч |
| Габариты (мм) | Передатчик: 31×16×11<br>Приёмник: 30×16×7,5<br>Кейс: 67×51×23 |
| Вес | Передатчик: 8 г Приёмник: 3 г<br>Кейс: 43 г |