
## Wireless Lavalier Microphone



**User Manual**


MADE IN CHINA

## Product Introduction

Thank you very much for choosing our product.


This product is a capsule-style lapel microphone that delivers professional-grade audio output for recording and live streaming. It is plug-and-play and requires no App. Its versatile applications include: online live streaming, video VLOG shooting, program interviews, interview recording, video teaching, and more.

The product consists of three parts: a transmitter, a receiver, and a charging case. As shown in the figure below:



Charging case　Transmitter　Receiver

## Product Functions



**Power Button**

Press and hold for 2s to power on
Press and hold for 2s to power off

Single click - Noise Reduction
Double click - Echo
Triple click - Mute

**Indicator Light**


Blue light blinking - Pairing
Blue light steady - Paired

Green light blinking - Charging
Green light off - Fully charged
Red light blinking - Low battery warning

Green light steady - Noise Reduction
Purple light steady - Echo
Red light steady - Mute

**Charging Contact**

## Product Functions



**Charging Port**

**Connection Light**


Blue light blinking - Pairing
Blue light steady - Paired

**Volume Level Indicator**

Level 1 •
Level 2 • •
Level 3 • • •

**Volume Button**

**Single click :**
Increase or decrease volume (cycles sequentially).
**Double click :**
Cycle through voice effects:
Childlike Voice - Deep Voice - Elegant Female Voice - Original Voice.
**Press and hold for 3s to lock pairing.**




**Battery Indicator Light**

• ○ ○ ○ —25%
• • ○ ○ —50%
• • • ○ —75%
• • • • —100%

**Charging Port**

## Usage Method


**Step 1:** Insert the receiver into your phone's port



Note: For OPPO, VIVO, IQOO, REALME, and brands that cannot connect, please search for "OTG" in your phone's settings and turn on OTG power supply for proper operation.

## Usage Method


**Step 2:** Remove the transmitter from the charging case. Once the Connection Light is steady, the microphone is ready for use.




## Phone Charging

While filming short videos or live streaming, you can charge your phone via the receiver's port.

⚠ Please use a charger rated at 5V/1A or lower.



## Product Operation

**Transmitter**

| Function/Status | Button/Action | Light Effect |
|---|---|---|
| Power On | Removal from charging case powers on (or press and hold Power button for 2s to power on) | Blue light blinking |
| Power Off | Placement into charging case powers off (or press and hold Power button for 2s to power off) | Light off |
| Not Connected | | Blue light blinking |
| Connected | | Blue light steady |
| Noise Reduction | Single click Power button (Click again to cancel) | Green light steady |
| Echo | Double click Power button (Double click again to cancel) | Purple light steady |
| Mute | Triple click Power button (Triple click again to cancel) | Red light steady |
| Charging | Place into charging case | Green light blinking |
| Fully Charged | | Green light off |
| Low Battery | | Red light blinking |

## Product Operation

**Receiver**

| Function/Status | Button/Action | Light Effect |
|---|---|---|
| Power On | Insert into device port for power | Blue light blinking |
| Power Off | Remove from device port to power off | Light off |
| Not Connected | | Blue light blinking |
| Connected | | Blue light steady |
| Pairing Locked | Press and hold Volume button for 3s | Blue light blinks 3 times, then stays steady |
| Volume Level Cycling | Single click Volume button | Number of blue lights increases sequentially |
| Voice Effects | Double click Volume button | Blue light blinking |

**Charging Case**

| Function/Status | Action | Light Effect |
|---|---|---|
| Charging | Plug in charging cable | Blue light blinking |
| Fully Charged | | Blue light steady |
| Low Battery | | Blue light rapid blinking |

## Product Parameter

| | |
|---|---|
| Wireless Transmission | 2.5GHz |
| Transmission Delay | <20ms |
| Frequency Response | 20Hz - 20kHz |
| Sensitivity | -36dB |
| Signal-to-Noise Ratio | -68dB |
| Transmission Range | 20m-50m |
| Single Mic Runtime | 4-5H |
| Dual Mic Runtime | Up to 16+ hours with charging case |
| Input Voltage | DC4.8~5.2V |
| Transmitter Battery | 60mAh |
| Charging Case Battery | 250mAh |
| Dimensions（mm） | Transmitter: 15.6×25.8×16.7<br>Receiver: 34.6×22.3×8.4<br>Charging Case: 64.3×46.3×25.6 |
| Weight | Transmitter: 6g　Receiver: 5g<br>Charging Case: 34g |