Wireless Microphone



User Manual

Product Introduction


Dear user, thank you for choosing to use our wireless lavalier microphone. This manual will provide you with clear usage guidelines to help you quickly get started and fully utilize the product's functions.
This product consists of three parts: microphone, receiver, and charging case. It can provide professional level recording and live streaming output, plug and play, without the need for an app, and can be used for online live streaming, video VLOG shooting, program interviews, interview recording, video teaching and other scenarios.



Charging case Microphone Receiving end


Usage Method

1. Take out the microphone and receiver



Usage Method

2. Insert the receiving end into the phone (the microphone and receiving end indicator light remain on for use).



Microphone - Button



Multi-function button

Power on/off--
Long press the multi-function button

Noise reduction mode--
Single click the multi-function button

Reverb mode--
Double click the multi-function button

Silent mode--
Three clicks the multi-function button

Microphone - Indicator light

Indicator light:



- Blue light flashing slowly - pairing in progress
- Blue light permanently on - paired
- Long green light on - charging medium green
- Light off- full of lightning flashes
- Red light - low battery
- Red light always on - wheat off

Long blue light on- noise reduction on

Long blue light on - Reverb on


Receiver - Button



Volume button:

Click the volume button to increase or Reduce volume (cycle in sequence)

Receiver - Indicator light



Paired indicator light

Blue light permanently on - paired

Blue light flashing slowly - pairing in progress

Microphone volume indicator light


first gear ·
second gear · ·
third gear · · ·

Charging Case

Digital display screen

Microphone charging indicator

Charging case power indicator



Charging port

Phone Charging

When shooting short videos or live broadcasts

The phone can be charged through the interface on the receiving end.



Charging port

Frequently Asked Question

1. Why can't I record normally after connecting to my phone?
*Please check if the connection indicator lights of the microphone and receiver are always on.
*Please check if the microphone battery is sufficient. If the battery is low, please charge it promptly.
*Some Xiaomi and Huawei phones need to update their phone versions (Settings > My Device > Version > Check for updates).
*Some brands of mobile phones, such as VIVO, OPPO, Realme, Oneplus, iQOO, etc., require the OTG "function to be turned on and external recording devices to be turned on
Step 1: Open the "OTG" process: Phone settings > Other settings > OTG > Open or search for "OTG" in the search box in the settings and open it)
Step 2: Open the external device process: Settings > Sound and Vibration > More Sound Settings > Default Recording Device > External Device
2. Can't the microphone record for the camera app that comes with the device?
*Some brands of mobile phones have strict restrictions on the system, which prevent the microphone from obtaining audio permissions, not due to the quality of the microphone. If this situation occurs, please contact the brand phone manufacturer.
*This product is compatible with the vast majority of apps on the market. Please try using other apps instead.
3. Is there noise in the recorded sound?
*Check if the microphone is in noise reduction mode (the second indicator light is always on). Click the multifunction button to turn on noise reduction.

Frequently Asked Question

4. Is the recorded sound too low?
*Please shorten the distance between the microphone and the sound source reasonably to avoid breaking the sound.
*Please click the microphone volume button on the receiving end to increase the volume.
*Some brands of mobile phones, such as VIVO, OPPO, Realme, Oneplus, iQOO, etc., require the "OTG" function to be turned on and external recording devices to be turned on (please follow the first step of the FAQ).
5. What should I do if there is wind noise?
*If you purchased a model equipped with a windshield, please install the windshield on the microphone.
6. What should I do if the connected phone has low battery during recording?
*Please connect the charging cable to the charging port on the receiving end to charge the phone.
7. What if there is an echo?
*Check if the microphone has the reverb function turned on (the third indicator light is on). Double click the multifunction button to turn o ff reverb.
*Enter the song request interface in the live broadcast room and set it to the original sound in the tuning section.
8. What if there is an echo during the live broadcast?
*Please turn o ffthe sound on your phone while watching the live broadcast, otherwise there will be echoes (phones in the same space cannot have sound while watching the live broadcast).

Product Parameters

Wireless transmission: 2.4GHz
Sound delay: <20ms
Frequency response: 20Hz-20kHz
Sensitivity: -35dB
Signal to noise ratio: -65dB
Transmission distance: 20 meters (turning) - 40 meters (visible)
Microphone: 360 degree omnidirectional
Range: Microphone: 6H
Paired with charging case: 23H
Battery capacity: Microphone: 80mAh
Charging case: 400mAh
Input voltage: DC 4.5-5.2V
Adapter: 5V/1A
Weight: Microphone: 9g
Receiver: 5g
Charging case: 64g
Size: Microphone: 24*10.3mm
Receiver: 42*15*7.5mm
Charging case: 74*32.7*41mm

Safety Precautions

1. The product contains strong magnetism. To avoid magnetization effects, please stay away from easily interfering devices such as magnetic cards, IC cards, implanted medical devices (such as pacemakers), hard drives, RAM chips, etc.
2. It is strictly prohibited to let the product come into contact with any liquid, and do not immerse the product in water or wet it. Do not use the product in rain or damp environments. After contact with water inside the product, corrosion reactions may occur, leading to battery self ignition or even explosion.
3. If the product catches fire, please immediately use water, water mist, sand, fire blanket powder, and carbon dioxide fire extinguishers to extinguish the fire. Please choose the fire extinguishing method in the order recommended above based on the actual situation.
4. Please use the product in an environment between -10°C and 45°C, with a charging environment temperature of 5°C to 45°C.
5. It is prohibited to disassemble the product in any way. If the battery is punctured during disassembly, it will lead to electrolyte leakage inside the battery, and even cause a fire or explosion.
6. Mechanical impact, rolling or throwing of products is prohibited. Do not place heavy objects on the product.
7. Do not place the product in the accessories or inside of heating equipment, cooking equipment, high-pressure containers, etc. (such as microwaves, battery ovens, electric ovens, electric heaters, high-pressure cookers, water heaters, gas stoves, etc.) to prevent the battery from overheating and exploding.

Safety Precautions

8. It is prohibited to place products near heat sources (such as stoves or heaters) or in cars on hot days. Do not store the product in an environment exceeding 60°C.
9. Do not store the battery for a long time after fully discharging it, to avoid damage to the battery cell caused by excessive discharge, and it will not be able to be used again.
10. The charging compartment, data cable, and battery of the original matching model must be used.
11. Using non certified or non matching charging compartment data cables or batteries may cause electric shock, fire, explosion, or other hazards.

Attention:
Due to product version upgrades or other reasons, this manual may be updated from time to time.
Unless otherwise agreed, this document is only intended as a guide for use. All statements, information, and suggestions in this document do not constitute any express or implied warranties.

PASS QC 01 Qualified

FC CE RoHS